

66-1 WARNING CHIME

2001 F53

For diagnostic information, refer to Section 413-09 of the Workshop Manual.

With a Body Builder supplied Door Jamb Switch, circuit should receive 12V when door is open.

Sends a 12V signal to the Warning Chime Module with switch in PARK or HEAD.

With LH front door courtesy lamp switch closed, the module will sound a warning if the key is left in the ignition, headlamps are left on or safety belt is not buckled.

