
## DAYTIME RUNNING LAMPS (DRL) 97-2



## CONNECTOR REFERENCE LIST

CONNECTOR	SECTION-PAGE
C274a	13-12

Refer to Location Index, Cell 152, for Component, Connector, Splice, Ground and Base Part Number descriptions and locations.